


RYCO FILTERS



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA264P. IVECO DAILY IV



1. The cabin air filter is located in the engine bay below the middle section of the windscreen.
2. Open the bonnet and refer to the round plastic housing in the centre section of the engine compartment closest to the firewall.
3. Undo the two (2) screws securing the housing and remove it.
4. Grab the old filter and remove carefully to avoid any accumulated debris from being spread around and clean the area. Slide the new filter in making sure it faces to the correct air flow direction and refit all components in reverse order.

GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

GUD Automotive -
A division of GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz