

RST200 REMOVAL AND FITMENT FILTER CUPS

Only use hand tools when handling RST200.

Do not use impact guns (pneumatic wrenches).

We recommend the use of a ½” ratchet or 27mm wrench to avoid damage to the cup.



What Does This Mean?

Warranty will be voided if pneumatic wrenches are used with any of the cups.



AUSTRALIA
GUD Automotive Pty Ltd
29 Taras Avenue, Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

NEW ZEALAND
GUD Automotive - A division of GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz

SOCIAL NETWORKS
Facebook: <http://facebook.com/rycofilters>
Twitter: http://twitter.com/Ryco_Filters